

Test Run and Commissioning Sheet

Serial Number

customer.	
Customer Name &	· ALLANTINA DA LOL A 11
Address:	LALMATIA Mohila College, Mohammad PUS.
Contact No:	MD: MIZANUR RAHAMANKHAMAEI:
COTTUCE TO:	Tel: 0 (75/6/04/0

Gen set: Product ID 20E13627 K (Plant No.): Model KVA Details Gen Set: PL-250 250KVA Brand Model No Serial No Engine: perkings BPEC Brand Model No Serial No Alternator: Year of Manufacturing Brand & Model Magnetic Capacity (Amp) Foreign **ATS Type** Nil Local ABB Contractor Local Canopy internal Good/Not **Canopy Sound** Good / Not Good Canopy Type Open Foreign insulation Good performance 12 Valt Controller Model 7120 MKII **Battery Charger** Connected Not Connected

Installation:

Place Of Installation	Mohammadpur	Date of Delivery	24.06.21
Date Of Installation	06.07.2027	Date Of Commissioning	07/07/21
Warranty Expiration date	365 days/1500 h	Free Service Period	
,	from date	of commiss	ioning.

Load Test

Item No	KW	Hz/Speed	Speed Voltage Phase-N Current		Voltage Phase-N		nt	Oil		
			V1-N	V2-N	V3-N	I1	12	13	Pressure Bar	Temperature °C
1		1500	231	232	232	28	25	48	512	740
2										16
3								****		
4										
5										
6				6,						-
7								***************************************		
8		-								
9								8		1
10										

CWG-QM/FORM-0043

Revision No.: 00

Page 1 of 2



Related Documents

User Manual	Yes	No	Electrical Diagram of Gen. Set	Yes	No
Maintenance/User Hand Book	Yes	No	Electrical Diagram of Foreign ATS	Yes	No

Warranty Dose Not Cover:

- Defects due to users improper maintenance (Not following the maintenance instruction by Manufacturer)
- All Consumable items (Not following the user guide/manual by Manufacturer)
- Normal Wear & Tear
- Calterations or repairs of any parts without prior approval by authorized Manufacturer/Distributor.
- **❸** Not Following written Instruction/Comments/Recommendation given by Commissioning Manager / Engineer.

For Cross World Group

For Customer

Commissioning Engineer

Date: 06 | 07 | 24

The Gen set has been commissioned successfully & handed over without any discrepancy. We understood the operational procedure.

Response Time	Fast	Slow	C	ustomer observ	ation about produ	uct & service
Product Problem	ОК	Not Ok	Delighted	Very	Satisfactory	Unsatisfactory
Identification				Satisfactory		
Operation Procedure	Ok	Not Ok	Remarks (I	fany):		
Explanation						
Service Engineer Behavior	Ok	Not Ok				
Additional Work /	Ok	Not Ok				
service/Commissioning Done						

CWG-QM/FORM-0043

Revision No.: 00

Page 2 of 2



COMPLETION CERTIFICATE

DATE:
To,
Project Name: Lal Matia Mobila College. Mohammad PUV
COMPLETION CERTIFICATE OF DIESEL GENERATING SET PLANT ID: 20613627 K
Dear Sir,
We have since completed installation, testing and commissioning of above generating set with model PM/PS/a50 and tested it as per ALLAM's manual on the Date 6 7 21 in presence of your representative/operator and found satisfactory performance in all respect and handed over its key and all the relevant standard accessories, equipment and manuals to your representative.
We have also explained your operator how to conduct daily, weekly, monthly as well as all other inspections/services as called for in the ALLAM 's manual for smooth and trouble free operation of this generator. We shall cover warranty for the next 12 (Twelve) months from the date of its delivery, as per ALLAM 's terms and conditions of sales.
If you disagree with us and have any other query, please inform us as soon as possible. If we do
not hear from you within next 7 (seven) days, contrary to what we have stated above, we shall consider that the plant has been received by you in a satisfactory condition.

Yours faithfully,
Cross World Power Ltd.

For and on behalf of

received the Plant in Good order & condition.

CWG-QM/FORM-0044A

Revision No.: 00

Page 1 of 2



DATE:

To,

Project Name: Lalmatia Mohila collage, Maham Mad PVV.

Dear Sir,

We would like to express our heartfelt gratitude for providing us the opportunity to serve you with our generator. The 250 KVA Tempest brand diesel generator has been commissioned and is presently running properly.

The product that Cross World supplies are of highest quality and would definitely outlive any generator that you have used in the past provided the generators are maintained properly. And to achieve that there is no alternative to routine servicing of the generators.

It is essential that the new generator must undergo routine servicing for the **first time after running for 120 hours, followed by routine servicing after every 200 hours of running.** During each routine servicing basically lube oil filter, fuel filter, coolant and lube oil needs to be changed. Air filter needs to be changed after every 400 hours of running. This is the standard rule, but if the generator is in dusty environment then the air filter may require changing at every 200 or less hours of running.

Saline water in the radiator would eventually damage the engine block, resulting in seizure of the engine. We suggest you to avoid using normal tap water in the radiator as well. Our recommendation is to use distilled water in the radiators. The radiator must also be serviced once every 400 hours of running if not earlier. Basically, if the above rules are followed strictly, your generators will have a service life of over 10 years without hassle.

All diesel generators are used as per their application (Prime/Stand By/Base load) recommended in ISO 8528.It is also recommended that the generators depending on the usage should follow the instruction as per O & M / User Manual and maintain a recommended ventilation system inside engine room.

There is another critical issue that is often overlooked by our clients. It is the air circulation within the generator room. The fresh cold air flow into the room is sucked in by the engine for combustion. To keep the ambient temperature to a minimum, a continuous in-flow and out-Flow of air is a must. Otherwise, if the ambient temperature reaches over 45°C, the engine temperature shoots up, resulting in premature shutdown.

We believe it is our prerogative to keep each of our customers aware of the critical issues regarding the products that we supply and we can only request you to instruct the persons responsible for maintenance of the gen set to inform us to perform routine servicing upon completion of the running hours mentioned above. In any case, we would have our engineers proactively contact your maintenance department time to time.

We hope the above information would be helpful for your maintenance team.

Thank you once again for extending your support.

Sincerely yours,
Cross World Group

Revision No.: 00

Page 2 of 2

CWG-QM/FORM-0044A



Electrical and Mechanical Installation Sheet

Project Name Address: Walk Walk		Ser	rial Numb	oer:	3
### STEP 1 : Check points when shipment arrive to site Engine & Alternator 1	Project I	Name 1 at 1 AAA C. H. MA ONE CO. O. O.	D/MD/0 deg	PI	- 257
### STEP 1 : Check points when shipment arrive to site Engine & Alternator 1	-	La a la a la l	Date	M	
No visual damage to engine or generator.	Address.	MO WANN WY LOO	Date	100	3.01121
Engine & Alternator 1 No visual damage to engine or generator. 2 Visual damage to engine or generator. 3 Gen set Placement (Leveling & botting) If there is any visual damage, please inform concern dept. Step 2 : Gen set room /environmental condition 1 Sufficient space around the cenerator for movement 2 Proper light and air inside the room 3 Dust proof, neat and clean Step 3 : Cable selection & termination 1 Check the power cable rating and insulation quality 2 Check the control & signal sable 3 Cable trench / tray (If any) 6 Power cable connections from Alternator - ACB, ACB-ATS, ATS-LT 7 LT/Load are correct (Balanced) 8 Phase Sequence Step 4 : Earthing System/connection 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5 : Exhaust/silencer System- 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 6 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket filtings and leveling 11 Botting, lightening & welding 11 Botting, lightening & welding 11 Botting, lightening & welding	STEP 1	Check points when shipment arrive to site	***************************************		Remarks
No visual damage to engine or generator.					
Visual damage to engine or generator. 3 Gen set Placement (Leveling & botting) If there is any visual damage, please inform concern dept. Step 2: Gen set room /environmental condition 1 Sufficient space around the generator for movement 2 Proper light and air inside the room 3 Dust proof, neat and clean Step 3: Cable selection & termination 1 Check the power cable rating and insulation quality 2 Check the control & signal cable 3 Cable laying & dressing 4 Cable marking & termination 5 Cable tench / tray (If any) 6 Power cable connections from Alternator - ACB, ACB-ATS, ATS-LT 7 LT/Load are correct (Balanced) 8 Phase Sequence Step 4: Earthing System/connection 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 1 Ducting Dimension					6
Sep set Placement (Leveling & botting)					
If there is any visual damage, please inform concern dept. Step 2 : Gen set room /environmental condition					
Step 2 : Gen set room /environmental condition					
1 Sufficient space around the generator for movement 2 Proper light and air inside the room 3 Dust proof, neat and clean Step 3: Cable selection & termination 1 Check the power cable rating and insulation quality 2 Check the control & signal cable 3 Cable laying & dressing 4 Cable marking & termination 5 Cable ternich / tray (If any) 6 Power cable connections from Alternator - ACB, ACB-ATS,ATS-LT 7 LT/Lod are correct (Balanced) 8 Phase Sequence Step 4: Earthing System/connection 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe 4 Support system 5 Extra floxible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Botting, lightening & welding STEP 6: Radiator System Ok Not ok Remarks STEP 6: Radiator System Ok Not ok Remarks	il there is	any visual damage, piease inform concern dept.			
1 Sufficient space around the generator for movement 2 Proper light and air inside the room 3 Dust proof, neat and clean Step 3: Cable selection & termination 1 Check the power cable rating and insulation quality 2 Check the control & signal cable 3 Cable laying & dressing 4 Cable marking & termination 5 Cable ternich / tray (If any) 6 Power cable connections from Alternator - ACB, ACB-ATS,ATS-LT 7 LT/Lod are correct (Balanced) 8 Phase Sequence Step 4: Earthing System/connection 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe 4 Support system 5 Extra floxible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Botting, lightening & welding STEP 6: Radiator System Ok Not ok Remarks STEP 6: Radiator System Ok Not ok Remarks	Step 2:	Gen set room /environmental condition	Ok	Not ok	Remarks
2 Proper light and air inside the room 3 Dust proof, neat and clean Step 3: Cable selection & termination 1 Check the power cable rating and insulation quality 2 Check the control & signal cable 3 Cable laying & dressing 4 Cable marking & termination 5 Cable teroch / tray (If any) 6 Power cable connections from Alternator - ACB, ACB-ATS,ATS-LT 7 LT/Load are correct (Balanced) 8 Phase Sequence Step 4: Earthing System/connection 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Botting, tightening & welding		,	1		
Step 3: Cable selection & termination 1 Check the power cable rating and insulation quality 2 Check the control & signal cable 3 Cable laying & dressing 4 Cable marking & termination 5 Cable terent/ tray (If any) 6 Power cable connections from Alternator - ACB, ACB-ATS, ATS-LT 7 LT/Load are correct (Balanced) 8 Phase Sequence Step 4: Earthing System/connection 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and levelling 11 Bolting, tightening & welding					
1 Check the power cable rating and insulation quality 2 Check the control & signal cable 3 Cable laying & dressing 4 Cable marking & termination 5 Cable trench / tray (If any) 6 Power cable connections from Alternator - ACB, ACB-ATS,ATS-LT 7 LT/Load are correct (Balanced) 8 Phase Sequence Step 4: Earthing System/connection Ok Not ok Remarks 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- Ok Not ok Remarks 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System 1 Ducting Dimension	3	Dust proof, neat and clean			
1 Check the power cable rating and insulation quality 2 Check the control & signal cable 3 Cable laying & dressing 4 Cable marking & termination 5 Cable trench / tray (If any) 6 Power cable connections from Alternator - ACB, ACB-ATS,ATS-LT 7 LT/Load are correct (Balanced) 8 Phase Sequence Step 4: Earthing System/connection Ok Not ok Remarks 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- Ok Not ok Remarks 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System 1 Ducting Dimension	Sten 3 ·	Cable selection & termination	Ok	Not ok	Remarks
2 Check the control & signal cable 3 Cable laying & dressing 4 Cable marking & termination 5 Cable trench / tray (If any) 6 Power cable connections from Alternator - ACB, ACB-ATS,ATS-LT 7 LT/Load are correct (Balanced) 8 Phase Sequence Step 4: Earthing System/connection Ok Not ok Remarks 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- Ok Not ok Remarks 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe * 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System 1 Ducting Dimension				THOU OIL	
Cable laying & dressing 4 Cable marking & termination 5 Cable trench / tray (if any) 6 Power cable connections from Alternator - ACB, ACB-ATS,ATS-LT 7 LT/Load are correct (Balanced) 8 Phase Sequence Step 4: Earthing System/connection 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- Ok Not ok Remarks 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System Ok Not ok Remarks			~		
4 Cable marking & termination 5 Cable trench / tray (If any) 6 Power cable connections from Alternator - ACB, ACB-ATS,ATS-LT 7 LT/Load are correct (Balanced) 8 Phase Sequence Step 4 : Earthing System/connection Ok Not ok Remarks 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5 : Exhaust/silencer System- Ok Not ok Remarks 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe * 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6 : Radiator System Ok Not ok Remarks			~		
5 Cable trench / tray (If any) 6 Power cable connections from Alternator - ACB, ACB-ATS,ATS-LT 7 LT/Load are correct (Balanced) 8 Phase Sequence Step 4: Earthing System/connection Ok Not ok Remarks 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- Ok Not ok Remarks 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe * 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Botting, tightening & welding STEP 6: Radiator System Ok Not ok Remarks			r		
7 LT/Load are correct (Balanced) 8 Phase Sequence Step 4: Earthing System/connection 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe * 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System 1 Ducting Dimension	5		~		
8 Phase Sequence Step 4: Earthing System/connection 1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe * 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System 1 Ducting Dimension	6	Power cable connections from Alternator - ACB, ACB-ATS,ATS-LT			
Step 4 : Earthing System/connection 1	7	LT/Load are correct (Balanced)			
1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe * 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System Ok Not ok Remarks	8	Phase Sequence	~		
1 Separate earthing for generator 2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe * 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System Ok Not ok Remarks					
2 Earthing result below 1 ohm 3 Connection from earthing bar to generator/ATS (body & neutral) Step 5: Exhaust/silencer System- Ok Not ok Remarks 1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe * 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System Ok Not ok Remarks	Step 4:	Earthing System/connection	Ok	Not ok	Remarks
Step 5 : Exhaust/silencer System- Mounting of Exhaust silencer Rigid / flexible fixing of exhaust pipe Diameter & Length of exhaust pipe * Support system Extra flexible if required Rain cap Insulation & Quality Alignment Drainage point Gasket fittings and leveling Bolting, tightening & welding STEP 6 : Radiator System Ok Not ok Remarks	1	Separate earthing for generator	~		
Step 5 : Exhaust/silencer System- 1	2	Earthing result below 1 ohm	~		
1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe * 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System Ok Not ok Remarks	3	Connection from earthing bar to generator/ATS (body & neutral)	~		
1 Mounting of Exhaust silencer 2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe * 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System Ok Not ok Remarks					
2 Rigid / flexible fixing of exhaust pipe 3 Diameter & Length of exhaust pipe * 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System 1 Ducting Dimension	Step 5:	Exhaust/silencer System-	Ok	Not ok	Remarks
3 Diameter & Length of exhaust pipe * 4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System 1 Ducting Dimension	1	Mounting of Exhaust silencer			
4 Support system 5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System 1 Ducting Dimension	2	Rigid / flexible fixing of exhaust pipe			
5 Extra flexible if required 6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System 1 Ducting Dimension	3	Diameter & Length of exhaust pipe *			,
6 Rain cap 7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System 1 Ducting Dimension	4	Support system			
7 Insulation & Quality 8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System 1 Ducting Dimension	5	Extra flexible if required			3
8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System Ok Not ok Remarks 1 Ducting Dimension	6	Rain cap			9
8 Alignment 9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System Ok Not ok Remarks 1 Ducting Dimension	7	Insulation & Quality			
9 Drainage point 10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System Ok Not ok Remarks 1 Ducting Dimension					
10 Gasket fittings and leveling 11 Bolting, tightening & welding STEP 6: Radiator System 1 Ducting Dimension Ok Not ok Remarks					
11 Bolting, tightening & welding STEP 6: Radiator System Ok Not ok Remarks 1 Ducting Dimension					
STEP 6 : Radiator System Ok Not ok Remarks 1 Ducting Dimension			-	1	×
1 Ducting Dimension	- 11	Politing, agricelling & weighing		1	
and so the	STEP 6:	Radiator System	Ok	Not ok	Remarks
and so the	1	Ducting Dimension	No.		
			NO		NOT USE

CWG-QM/FORM-0042

Revision No.: 00

Page 1 of 2



3	Canvas cloth fitting		13
4	Support system .	,	
5	Out flow / louver	~	
6	Water Drain line	V	
7	Coolant Spec	~	
8	DM Water		

TEP 7	: Fuel System	Ok	Not ok	Remarks
1	Check fuel day tank placement / capacity *	1		
2	Check fuel reservoir placement / capacity *			-
3	Fuel feed line (MS pipe Diameter)	-		,
4	Fuel return line (MS pipe ,Diameter)	-		
5	Fuel tank height & size/capacity (for 4000 series)	_		

STEP 8	TEP 8 : Ventilation System		Not ok	Remarks
1	Check all ventilation blowers are installed as per engine requirement, wiring and its connection to DB/MCC.	~		
2	Ducting for ventilation system	<u></u>		
3	Check the air flow/capacity of the ventilation fan	-		-
3	Louver/ ventilation fan placement / condition checking (if necessary)			
4	Pre-filtration system for air intake	✓		

STEP 9): Miscellaneous	Ok	Not ok	Remarks
1	Breather pipe extension	~		
2	Battery terminal connection and its condition.	~		
3	Check availability of distilled water, lube oil, coolant and diesel for commissioning as required	~		
4	Check hanging condition of the ATS on the wall.	~		
5	Visual condition of the Canopy, ATS, Fuel tank etc.	~		
6	Lube oil drain line	~		
7	Check and make overall comment on environmental condition to run the generator			E.

We have checked and certify that the works mentioned above has done as per our drawing/design/requirements/recommendations.

Cross world Personnel	mah Tas	Signed :	Date : 08 7 24
End user personnel	MIZAN	Signed _:	Date : 7.7.21

CWG-QM/FORM-0042

Revision No.: 00

Page 2 of 2